# CHAPTER 5

**Prepared by: Prof. Dr. Farouk Majeed Muhauwiss** Civil Engineering Department – College of Engineering Tikrit University

## SETTLEMENT OF BUILDINGS

## **5.1 TYPES OF SETTLEMENT**

Settlement is a term that describes the vertical displacement of a structure, footing, road or embankment due to the downward movement of a point.

From structural point of view, settlement of structures may be of two types:

• <u>Equal or uniform settlement</u>: This type has no serious implication on the structure or civil engineering performance of the building. However, it should have a maximum limit to prevent the failure of soil under the structure.

• **<u>Differential settlement:</u>** It means that one point of the structure settles more or less than the others, therefore, it may lead to damage of the superstructure. Usually it occurs due to one or more of the following:

- 1. Variation of soil stratum (the subsoil is not homogeneous).
- 2. Variation in loading condition.
- **3.** Large loaded area on flexible footing.
- 4. Differential difference in time of construction, and
- 5. Ground condition, such as slopes.

## **5.2 TILTING OF FOUNDATIONS**

The limiting values of foundation tilting are presented in Table (5.1) and can be calculated as:

$$\tan_{\omega_{\rm L}} = \frac{M_{\rm L}}{L^2 B} \frac{1 - \mu_{\rm S}^2}{E_{\rm S}} I_{\rm m}$$
 .....(5.1a)

$$\tan_{\omega_{B}} = \frac{M_{B}}{B^{2} L} \frac{1 - \mu_{s}^{2}}{E_{s}} I_{m}$$
(5.1b)

where,

 $M_L$  = moment in L - direction = Q.  $e_L$ 

 $M_B$  = moment in B - direction = Q.  $e_B$ 

 $\omega_L$  and  $\omega_B =$  tilting angles in L and B directions, respectively, and

 $I_m$  = moment factor that depends on the footing size as given in Table (5.2).

ω ( <i>in radians</i> )	Result to structure
1/150	Major damage
1/250	Tilting becomes visible
1/300	First cracks appear
1/500	No cracks (safe limit)

 Table (5.1): Effect of foundation tilting on structures.

## Table (5.2): Values of $\ I_m$ for various footing shapes.

Footing type		Im
Circular		6.00
Rectangular with $L/B =$	1.00 (Square)	3.70
	1.50	5.12
	1.25	5.00
	2.00	5.38
	2.50	5.71
	5.00	5.82
	10.0	5.93
	$\infty$ (Strip)	5.10

## **5.3 LIMITING VALUES OF SETTLEMENT PARAMETERS**

Many investigators and building codes recommended the allowable values for the various parameters of total and differential settlements as presented in Tables (5.3 - 5.6).

Table (5.3): Limiting values	of maximum to	tal settlemen	t, maximum differentia	I settlement,
and max	imum angular di	stortion for b	ouilding purposes	
	(		10	

(Skempton and	MacDonald,	1956).
---------------	------------	--------

	Settlement (mm)			
Settlement parameter	Sa	nd	Clay	
	Ref.1	Ref.2	<i>Rf.2</i>	
Maximum total settlement, $S_{T(max.)}$	20	32	45	
Maximum differential settlement, $\Delta S_{T(max.)}$				
<ul><li> Isolated foundations.</li><li> Raft foundations.</li></ul>	25 50	51 51-76	76 76 - 127	
Maximum angular distortion, $eta_{max.}$		1/300		

Ref. 1 - Terzaghi and Peck (1948), Ref. 2 - Skempton and MacDonald (1956)

Table (5.4):	Limiting	values o	of deflection	ratios
--------------	----------	----------	---------------	--------

Duilding ture	Deflection 1	ratio $(\Delta/L)$	Average maximum	
Building type	Sand	Clay	(cm)	
Steel and concrete frames	0.0010	0.0013	10	
Multistory buildings $L/H \leq 3$ $L/H \geq 5$	0.003 0.005	0.004 0.007	8 $L/H \ge 2.5$ 10 $L/H \le 1.5$	
One-story building	0.001	0.001		
Water towers, Ring foundations	0.004	0.004		

(The 1955 Soviet Code of Practice).

L = length between two adjacent points under consideration, and

H = height of wall above foundation.

Table (5.5): Limiting angular distortion for various structures
(Bjerrum, 1963).

Category of potential damage	Angular distortion $\beta_{max.}$
Safe limit for flexible brick walls $(L/H > 4)$	1/150
Danger for structural damage of general buildings	1/150
Cracking in panel and brick walls	1/150
Visible tilting of high rigid buildings	1/250
First cracking in panel walls	1/300
Safe limit of no cracking of building	1/500
Danger for frames with diagonals	1/600

Item	Parameter	Magnitude	Comments
Limiting values for serviceability	S <sub>T</sub>	25 mm 50 mm	Isolated shallow foundation Raft foundation
	$\Delta S_T$	5 mm 10 mm 20 mm	Frames with rigid cladding Frames with flexible cladding Open frames
	β	1/500	
Maximum acceptable foundation movement	S <sub>T</sub>	50mm	Isolated shallow foundation
<i>j</i>	$\Delta S_T$	20mm	Isolated shallow foundation
	β	≈1/500	

## Table (5.6): Recommendation of European Committee for Standardization(1994) on differential settlement parameters.

## **5.4 COMPONENTS OF TOTAL SETTLEMENT**

Foundation settlement mainly consists of three components (see Fig. (5.1)):

- (i) <u>Immediate settlement ( $S_i$ ):</u> occurs due to elastic deformation of soil particles upon load application with no change in water content.
- (ii) <u>Primary consolidation settlement ( $S_c$ )</u>: occurs as the result of volume change in saturated fine grained soils due to expulsion of water from the void spaces of the soil mass with time.
- (iii) <u>Secondary consolidation settlement (S<sub>sc</sub>)</u>: occurs after the completion of the primary consolidation due to plastic deformation of soil (reorientation of the soil particles). It forms the major part of settlement in highly organic soils and peats.

:.

 $S_T = S_i + S_c + S_{sc}$  .....(5.2)

These components occur in different types of soils with varying circumstances:

- <u>For clay:</u>  $S_T = S_i$  (minimum) +  $S_c$  (major) +  $S_{sc}$  (small, but present to certain extent) Therefore, for clay these settlements must be calculated.
- For sand:  $S_T = S_i$  (major) +  $S_c$  (present but mixed with  $S_i$ ) +  $S_{sc}$  (undefined) Since sand is permeable, therefore, Terzaghi theory cannot be applicable.



Fig. (5.1): Settlement versus time relationship.

## **5.5 METHODS OF COMPUTING IMMEDIATE SETTLEMENT**

Many methods are available to calculate the elastic (immediate) settlement of shallow foundations. But, only those methods of practical interest are discussed herein:

- 1. Theory of Elasticity method for granular soils or partially saturated clays.
- 2. Schmertmann method for granular soils.
- 3. Bjerrum method for layered clay under undrained condition.

## 5.5.1 Immediate Settlement Based on the Theory of Elasticity

The elastic settlement of a footing rested on *granular soils or partially saturated clays*, can be estimated using the elastic theory as (see Fig.(5.2)):



$$S_{i(average)} = 0.85.S_{i(center)}$$
.....(5.5)



Fig. (5.2): Elastic settlement of flexible and rigid foundations.

where,

 $S_i$  = immediate or elastic,

 $q_{0}$  = net applied pressure on the foundation,

B' = B/2 for center of foundation, and

= **B** <u>for corners</u> of foundation,

 $\mu_s$  = Poisson's ratio of soil, (see Table (5.7) for typical values).

 $E_s$  = weighted average modulus of elasticity of the soil over a depth of H. For a multi-layered soil stratum it is computed as:

$$E_{s(avg.)} = \frac{\sum Es_{(i)}.H_i}{\sum H_i}$$

in which,  $H_i$  and  $E_i$  are the thickness and modulus of elasticity of layer **i**, and  $\sum H_i = \mathbf{H}$  (the depth of hard stratum) or **5B** whichever is smaller, (see Table (5.8) for typical values of  $E_s$ ).

 $I_s$  = Shape factor (Steinbrenner, 1934) computed by:

$$\boldsymbol{I}_s = \boldsymbol{I}_1 + \frac{1-2\mu_s}{1-\mu_s}\boldsymbol{I}_2$$

where,  $I_1$ ...and... $I_2$  are influence factors = f(H/B', ..L/B) <u>obtained from Table (5.9)</u>, and H = depth of hard stratum

$$I_D$$
 = Depth factor (Fox, 1948) =  $f(D_f / B_1, \mu_s, and L / B)$  which can be approximated by:

$$I_{\rm D} = 0.66 \left(\frac{D_{\rm f}}{\rm B}\right)^{(-0.19)} + 0.025 \left(\frac{\rm L}{\rm B} + 12\mu_{\rm s} - 4.6\right)$$

<u>Note</u>: when  $D_f = 0$ , the value of  $I_D = 1$  in all cases.

 $C_N$  = Number of contributing corners = 4 *for center*, 2 *for edges*, and 1 *for corners*.

### Table (5.8): Typical values of $E_s$ for selected soils

(filed values depend on stress history, water content, density, etc.).

Table (5.7). Typical values of	$\mu_s$ .
Type of Soil	$\mu_s$
Clay, saturated	0.40 - 0.50
Clay, unsaturated	0.10 - 0.30
Sandy clay	0.20 - 0.30
Silt	0.30 - 0.35
Sand (dense)	0.20 - 0.40
Coarse (void ratio $= 0.4 - 0.7$ )	0.15
Fine-grained (void ratio = $0.4 - 0.7$ )	0.25
Rock	0.10 - 0.40
Loess	0.10 – 0.30
Concrete	0.15

Type of Soil	E <sub>s</sub> (MPa)
Clay	
Very soft	2-15
Soft	5-25
Medium	15-50
Hard	50-100
Sandy	25-250
Glacial till	
Loose	10-153
Dense	144-720
Very Dense	478-1440
Loess	14-57
Sand	
Silty	7-21
Loose	10-24
Dense	48-81
Sand and gravel	
Loose	48-144
Dense	96-192
Shale	144-14400
Silt	2-20

### Table (5.7): Typical values of $\mu_s$

## Table (5.9a): Values of $I_1$ to compute Steinbrenner's influence factor

				L	$I_s = I_1$	$+\frac{l-2}{l-\mu}$	$\frac{\mu_s}{\mu_s}I_2.$				
						L/B					
H/B'	1.0	1.1	1.2	1.3	1.4	1.5	1.6	1.7	1.8	1.9	2
0.2	0.009	0.008	0.008	0.008	0.008	0.008	0.007	0.007	0.007	0.007	0.007
0.4	0.033	0.032	0.031	0.030	0.029	0.028	0.028	0.027	0.027	0.027	0.027
0.6	0.066	0.064	0.063	0.061	0.060	0.059	0.058	0.057	0.056	0.056	0.055
0.8	0.104	0.102	0.100	0.098	0.096	0.095	0.093	0.092	0.091	0.090	0.089
1.0	0.142	0.140	0.138	0.136	0.134	0.132	0.130	0.129	0.127	0.126	0.125
1.5	0.224	0.224	0.224	0.223	0.222	0.220	0.219	0.217	0.216	0.214	0.213
2	0.285	0.288	0.290	0.292	0.292	0.292	0.292	0.292	0.291	0.290	0.289
3	0.363	0.372	0.378	0.384	0.389	0.393	0.396	0.398	0.400	0.401	0.402
4	0.408	0.421	0.431	0.440	0.448	0.455	0.460	0.465	0.469	0.473	0.476
5	0.437	0.452	0.465	0.477	0.487	0.496	0.503	0.510	0.516	0.522	0.526
6	0.457	0.473	0.488	0.501	0.513	0.524	0.533	0.542	0.549	0.556	0.562
7	0.471	0.489	0.506	0.520	0.533	0.545	0.556	0.566	0.575	0.583	0.590
8	0.482	0.502	0.519	0.534	0.549	0.561	0.573	0.584	0.594	0.602	0.611
9	0.491	0.511	0.529	0.545	0.560	0.574	0.587	0.598	0.609	0.618	0.627
10	0.498	0.519	0.537	0.554	0.570	0.584	0.597	0.610	0.621	0.631	0.641
20	0.529	0.553	0.575	0.595	0.614	0.631	0.647	0.662	0.677	0.690	0.702
500	0.560	0.586	0.612	0.635	0.656	0.677	0.696	0.714	0.731	0.748	0.763

		L/B									
H/B'											
	2.5	4	5	6	7	8	9	10	25	50	100
0.2	0.007	0.006	0.006	0.006	0.006	0.006	0.006	0.006	0.006	0.006	0.006
0.4	0.026	0.024	0.024	0.024	0.024	0.024	0.024	0.024	0.024	0.024	0.024
0.6	0.053	0.051	0.050	0.050	0.050	0.049	0.049	0.049	0.049	0.049	0.049
0.8	0.086	0.082	0.081	0.080	0.080	0.080	0.093	0.092	0.091	0.090	0.089
1.0	0.121	0.115	0.113	0.112	0.112	0.112	0.111	0.111	0.110	0.110	0.110
1.5	0.207	0.197	0.194	0.192	0.191	0.190	0.190	0.189	0.188	0.188	0.188
2	0.284	0.271	0.267	0.264	0.262	0.261	0.260	0.259	0.257	0.256	0.256
3	0.402	0.392	0.386	0.382	0.378	0.376	0.374	0.373	0.378	0.367	0.367
4	0.484	0.484	0.479	0.474	0.470	0.440	0.464	0.462	0.453	0.451	0.451
5	0.543	0.554	0.552	0.548	0.543	0.540	0.536	0.534	0.522	0.522	0.519
6	0.585	0.609	0.610	0.608	0.604	0.601	0.598	0.595	0.579	0.576	0.575
7	0.618	0.653	0.658	0.658	0.656	0.653	0.650	0.647	0.628	0.624	0.623
8	0.643	0.688	0.697	0.700	0.700	0.698	0.695	0.692	0.672	0.666	0.665
9	0.663	0.716	0.730	0.736	0.737	0.736	0.735	0.732	0.710	0.704	0.702
10	0.679	0.740	0.758	0.766	0.770	0.770	0.770	0.768	0.745	0.738	0.735
20	0.756	0.856	0.896	0.925	0.945	0.959	0.969	0.977	0.982	0.965	0.957
500	0.832	0.977	1.046	1.102	1.150	1.191	1.227	1.259	1.532	1.721	1.879

 $\mathbf{B}' = \mathbf{B}/\mathbf{2}$  for center of foundation, and  $= \mathbf{B}$  for corners of foundation,  $\mathbf{H} = depth of hard stratum (rock) under the footing.$ 

## Table (5.9b): Values of $I_2$ to compute Steinbrenner's influence factor $l-2\mu_s$

				<i>I</i> <sub>s</sub> =	$=I_1 + \frac{I_1}{I_1}$	$\frac{2\mu_s}{l-\mu_s}$	$I_2$ .				
						L/B					
H/B'	1.0	1.1	1.2	1.3	1.4	1.5	1.6	1.7	1.8	1.9	2
0.2	0.041	0.042	0.042	0.042	0.042	0.042	0.043	0.043	0.043	0.043	0.043
0.4	0.066	0.068	0.069	0.070	0.070	0.071	0.071	0.072	0.072	0.073	0.073
0.6	0.079	0.081	0.083	0.085	0.087	0.088	0.089	0.090	0.091	0.091	0.092
0.8	0.083	0.087	0.090	0.093	0.095	0.097	0.098	0.100	0.101	0.102	0.103
1.0	0.083	0.088	0.091	0.095	0.098	0.100	0.102	0.104	0.106	0.108	0.109
1.5	0.075	0.080	0.084	0.089	0.093	0.096	0.099	0.102	0.105	0.108	0.110
2	0.064	0.069	0.074	0.078	0.083	0.086	0.090	0.094	0.097	0.100	0.102
3	0.048	0.052	0.056	0.060	0.064	0.068	0.071	0.075	0.078	0.081	0.084
4	0.037	0.041	0.044	0.048	0.051	0.054	0.057	0.060	0.063	0.066	0.069
5	0.031	0.034	0.036	0.039	0.042	0.045	0.048	0.050	0.053	0.055	0.058
6	0.026	0.028	0.031	0.033	0.036	0.038	0.040	0.043	0.045	0.047	0.050
7	0.022	0.024	0.027	0.029	0.031	0.033	0.035	0.037	0.039	0.041	0.043
8	0.020	0.022	0.023	0.025	0.027	0.029	0.031	0.033	0.035	0.036	0.038
9	0.017	0.019	0.021	0.023	0.024	0.026	0.028	0.029	0.031	0.033	0.034
10	0.016	0.017	0.019	0.020	0.022	0.023	0.025	0.027	0.028	0.030	0.031
20	0.008	0.099	0.010	0.010	0.011	0.012	0.013	0.013	0.014	0.015	0.016
500	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.001	0.001	0.001

		L/B									
H/B'											
	2.5	4	5	6	7	8	9	10	25	50	100
0.2	0.043	0.044	0.044	0.044	0.044	0.044	0.044	0.044	0.044	0.044	0.044
0.4	0.074	0.075	0.075	0.075	0.076	0.076	0.076	0.076	0.076	0.076	0.076
0.6	0.094	0.097	0.097	0.098	0.098	0.098	0.098	0.098	0.098	0.098	0.098
0.8	0.107	0.111	0.112	0.113	0.113	0.113	0.113	0.114	0.114	0.114	0.114
1.0	0.114	0.120	0.122	0.123	0.123	0.124	0.124	0.124	0.125	0.125	0.125
1.5	0.118	0.130	0.134	0.136	0.137	0.138	0.138	0.139	0.140	0.140	0.140
2	0.114	0.131	0.136	0.139	0.141	0.143	0.144	0.145	0.147	0.147	0.148
3	0.097	0.122	0.131	0.137	0.141	0.144	0.145	0.147	0.152	0.153	0.154
4	0.082	0.110	0.121	0.129	0.135	0.139	0.142	0.145	0.154	0.155	0.156
5	0.070	0.098	0.111	0.120	0.128	0.133	0.137	0.140	0.154	0.156	0.157
6	0.060	0.087	0.101	0.111	0.120	0.126	0.131	0.135	0.153	0.157	0.157
7	0.053	0.078	0.092	0.103	0.112	0.119	0.125	0.129	0.152	0.157	0.158
8	0.047	0.071	0.084	0.095	0.104	0.112	0.118	0.124	0.151	0.156	0.158
9	0.042	0.064	0.077	0.088	0.097	0.105	0.112	0.118	0.149	0.156	0.158
10	0.038	0.059	0.071	0.082	0.091	0.099	0.106	0.112	0.147	0.156	0.158
20	0.020	0.031	0.039	0.046	0.053	0.059	0.065	0.071	0.124	0.148	0.156
500	0.001	0.001	0.002	0.002	0.002	0.003	0.003	0.003	0.008	0.016	0.031

B′	=	<b>B</b> /2 <u>for center</u> of foundation, and = <b>B</b> <u>for corners</u> of foundation,
Η	=	depth of hard stratum (rock) under the footing.

## 5.5.2 Schmertmann's Method (1978): Use of Strain Influence Factor

This method is based on the Dutch cone penetration resistance  $q_c$  using the strain influence factor diagram. It is proposed for two cases, square foundation (L/B = 1) where axisymmetric stress and strain conditions occur and strip foundation (L/B = 10) where plane strain conditions exist.

For square foundation: 
$$S_{i} = \frac{C_{1}C_{2}}{2.5} \Delta p \sum_{0}^{2B} \frac{I_{z}\Delta z}{q_{c}}$$
....(5.6a)

For strip foundation:

$$S_{i} = \frac{C_{1}C_{2}}{3.5} \Delta p \sum_{0}^{4B} \frac{I_{z}\Delta z}{q_{c}}$$
(5.6b)

where, P = gross applied pressure,

 $P'_{o}$  = effective stress at the foundation level,

 $\Delta P$  = net applied pressure = P - P'\_{o} (in kN/m^2),

 $q_c$  = cone end resistance, kN/m<sup>2</sup>, for each soil layer,

 $\Delta z =$  thickness for each soil layer, (in meters),

 $C_1 = \text{correction for depth of foundation} = 1 - 0.5 \frac{P'_o}{\Delta p} \ge 0.5$ 

 $C_2$  = correction for creep or time related settlement = 1+0.2 log<sub>10</sub>  $\frac{t}{0.1}$ 

- t = time in (years) after construction,
- $I_z$  = average strain influence factor for each soil layer obtained as the value at the mid-point of each soil layer from a diagram drawn alongside the  $q_c$  depth graph with a depth of 2B for square foundation and 4B for strip foundation as shown in **Fig.(5.3)**, and

 $I_{z \max} = 0.5 + 0.1 \sqrt{\frac{\Delta p}{\sigma v'}}$  is the maximum value of  $I_z$ , where  $\sigma'_v =$  vertical effective stress at a depth of B/2 for a square foundation and B for strip foundation.

#### Notes:

- Values of  $\Delta z$ , average  $q_c$  and average  $I_z$  for each soil layer are required for the summation term.
- Settlements for shapes intermediate between square and strip can be obtained by interpolation.



## 5.5.3 Bjerrum's Method for Average Settlement of Layered Clay Soil

$$S_{i(average)flexible} = \mu_0 . \mu_1 \frac{q.B}{E_u} .....(5.7)$$

where,  $\mu_0$  and  $\mu_1$  are factors for depth of embedment and thickness of soil layer beneath the foundation, respectively; obtained from **Fig.(5.4**). Remember that the principle of layering could be applied with this method such that the overlapping is equal to the number of layers -1.



Fig.(5.4): Coefficients of vertical displacement for foundations on saturated clays (after Janbu et al., 1956).

- **Problem (5.1):** A (5m x 10m) rectangular flexible foundation is placed on two layers of clay, both 10m thick as shown in the figure below. The modulus of elasticity of the upper layer is 8 MN/m<sup>2</sup> and that of the lower layer is 16 MN/m<sup>2</sup>. Determine the immediate settlement at the center of the foundation using:
  - (1) Elastic Theory Method. (2) Bjerrum Method. 10m 10m  $S_i$   $E_{u1} = 8 \text{ MN/m}^2, \mu_s = 0.3$  $E_{u2} = 16 \text{ MN/m}^2, \mu_s = 0.3$

Solution:

## (1) (Elastic Theory Method):

## (2) (Bjerrum Method):

- Settlement of 1<sup>st</sup>. layer (average settlement): From Fig.(5.4): for  $D_f/B = 0$  and L/B = 2;  $\mu_0 = 1.00$ For H/B = 10/5 = 2 and L/B = 2;  $\mu_1 = 0.70$   $S_{i(average)flexible} = \mu_0 . \mu_1 \frac{q.B}{E_u}$ .....(5.7)  $S_{1(average)flexible} = (1.00)(0.70) \frac{(75)(5)(1000)}{(8x1000)} = 32.81 \text{ mm}$
- Settlement of 2<sup>nd</sup>. layer (average settlement):

From **Fig.(5.4):** for  $D_f/B = 0$  and L/B = 2;  $\mu_0 = 1.00$ For H/B = 20/5 = 4 and L/B = 2;  $\mu_1 = 0.85$  $S_{2(average)flexible} = (1.00)(0.85) \frac{(75)(5)(1000)}{(16x1000)} = 19.92 \text{ mm}$ 

• The interaction between the 1<sup>st</sup>. and 2<sup>nd</sup>. Layers:

 $S_{3(\text{average })\text{flexible}} = (1.00)(0.70)\frac{(75)(5)(1000)}{(16x1000)} = 16.41 \text{ mm}$ 

The immediate settlement at foundation center =  $S_1 + S_2 - S_3$ = 32.81 + 19.92 - 16.41 = 36.32 mm

## **Problem (5.2):** (Schmertmann's method-settlement on sand)

A  $(3m \times 3m)$  square footing rested at a depth of (2m) below the ground surface. Estimate the immediate settlement of the footing under the load and soil conditions shown in the figure below after (0.1 year) from construction.



## Solution:

For square foundation:

$$S_{i} = \frac{C_{1}C_{2}}{2.5} \Delta p \sum_{0}^{2B} \frac{I_{z}\Delta z}{q_{c}} .....(5.6a)$$

• 
$$C_1 = \text{ correction for depth of foundation} = 1 - 0.5 \frac{P'_o}{\Delta p} \ge 0.5$$

 $P'_0$  = effective stress at the foundation level =  $D_f \cdot \gamma = 2(20) = 40 \text{ kN/m}^2$ 

 $\Delta P$  = net increase in stress at footing level = P - P'\_0 =  $\frac{1.8 \times 10^3}{3 \times 3} - 40 = 160 \text{ kN/m}^2$ 

$$C_1 = 1 - 0.5 \frac{40}{160} = 0.875 > 0.5$$
 (O.K.)

• 
$$C_2 = \text{Time correction factor} = 1 + 0.2 \log_{10} \frac{t}{0.1} = 1 + 0.2 \log_{10} \frac{0.1}{0.1} = 1.0$$

No.	$\Delta_{\mathbf{Z}}(\mathbf{m})$	q <sub>c</sub>	I <sub>Z</sub> (average)	$\frac{\Delta_{\rm Z}.{\rm I}_{\rm Z}}{\rm q_c}$
1	1.0	5000	(0+0.4)/2=0.2	0.000040
2	0.5	10000	0.5	0.000025
3	3.5	10000	0.366	0.000128
4	1.0	5000	0.066	0.0000132
				$\sum 20.62 \times 10^{-5}$

$$S_i = \frac{(0.875)(1.0)}{2.5} (160)(20.62 \times 10^{-5}) = 0.01155 \text{ mm} = 11.55 \text{ mm}$$

#### **Problem (5.3):** (Total immediate settlement)

Determine the total immediate settlement of the rectangular footing shown in figure below after 2 months.



#### Solution:

Since the soil profile is made up of two different soils, then the total immediate settlement will be:

 $S_{i(Total)} = S_{i(clay)} + S_{i(sand)}$ 

#### • Immediate Settlement of clay by Bjerrum's method:

 $S_{i(average)flexible} = \mu_0 . \mu_1 \frac{q.B}{E_u}$ .....(5.7)

From Fig.(5.4): for  $D_f / B = 1/3 = 0.33$  and L/B = 4/3 = 1.33;  $\mu_0 = 0.93$ 

for H/B = 2/3 = 0.66 and L/B = 1.33;  $\mu_1$  = 0.38

$$S_{1(\text{average})\text{flexible}} = (0.93)(0.38)\frac{(1200/3x4)(3)(1000)}{(2x8x1000)} = \underline{6.6 \text{ mm}}$$

• Immediate Settlement of sand by Schmertmann's method: For square foundation:

$$S_{i} = \frac{C_{1}C_{2}}{2.5} \Delta p \sum_{0}^{2B} \frac{I_{z} \Delta z}{q_{c}}$$
(5.6a)

$$C_{1} = 1 - 0.5 \frac{P'_{o}}{\Delta p} \ge 0.5$$
  
At foundation level:  
$$P'_{o} = D_{f} \cdot \gamma = 1(20) = 20 \text{ kN/m}^{2}, \quad \Delta P = P / A - P'_{o} = \frac{1200}{3x4} - 20 = 80 \text{ kN/m}^{2}.$$

On sand surface:

$$\begin{aligned} P_0' &= D_f \cdot \gamma = 3(20) = 60 \text{ kN/m}^2, \quad \Delta P = \frac{(80)(3)(4)}{(3+2)(4+2)} = 32 \text{ kN/m}^2 \ (2.1 \text{ method}) \\ C_1 &= 1 - 0.5 \frac{60}{32} = 0.06 < 0.5 \quad \therefore \quad \text{Use} \quad C_1 = 0.5 \\ C_2 &= 1 + 0.2 \log_{10} \frac{t}{0.1} = 1 + 0.2 \log_{10} \frac{2/12}{0.1} = 1.04 \\ I_{z(\text{avg.})} &= \frac{0.533 + 0.133}{2} = 0.333, \quad \frac{I_z \cdot \Delta z}{E} = \frac{(0.333)(3)}{20000} = 4.9.\text{ x} \cdot 10^{-5} \\ S_{i(\text{sand})} &= (0.5)(1.04)(32)(4.9.\text{ x} \cdot 10^{-5}) = \underline{0.815 \text{ mm}} \\ \therefore \quad S_{i(\text{Total})} = 6.6 + 0.815 = \underline{7.415 \text{ mm}} \end{aligned}$$

**Home work:** Redo problem (5.3) but with sand instead of clay as shown in the figure below. (Ans.:  $S_{i(Total)} = 5.75 \text{ mm}$ ).



## **5.6 PRIMARY CONSOLIDATION SETTLEMENT**

## **5.6.1 Compression Index** $C_c$ Method:

This method is adopted for normally and lightly overconsolidated clays. The compression index  $C_c$  is the gradient of e - log P plot for normally consolidated clay. While for overconsolidated clay,  $C_c$  is also the slope of the e - log P but beyond the preconsolidation pressure  $P'_c$ .  $C_c$  values

obtained from oedometer tests are likely to be underestimated due to sampling disturbance. Therefore, some correlations which relate  $C_c$  with soil composition parameter have been published and two of them are as follows:

$$C_c = 0.009(LL - 10)$$
 ...... (Terzaghi and Peck, 1948)  
 $C_c \approx 0.5\rho_s \frac{PI}{100}$ ...... (Wroth, 1979)

where, LL = liquid limit, PI = plasticity index, and  $\rho_s =$  particle density.

## Method (A):

- 1. Calculate the effective pressure  $\sigma'_o$  at center of the clay layer before the application of load.
- 2. Calculate the weighted average pressure increase at mid of clay layer using Simpson's rule:

$$\Delta \sigma_{\text{avg.}} = \frac{1}{6} (\Delta \sigma_{\text{t}} + 4\Delta \sigma_{\text{m}} + \Delta \sigma_{\text{b}})$$

where,  $\Delta \sigma_t$ ,  $\Delta \sigma_m$ , and  $\Delta \sigma_b$  are respectively the pressure increase due to applied load at the top, middle and bottom of clay layer.

- **3.** Using  $\sigma'_{o}$  and  $\Delta \sigma_{avg.}$  calculated above, obtain  $\Delta e$  from equations below, whichever is applicable.
  - (i) If  $\sigma'_p < \sigma'_o$ , the soil is under consolidated:

$$\Delta e = C_c \log_{10} \frac{\sigma'_o + \Delta \sigma_{avg.}}{\sigma'_p}$$
(5.8a)

(ii) If  $\sigma'_p = \sigma'_0$  (OCR = 1), the soil is normally consolidated:

$$\Delta \mathbf{e} = \mathbf{C}_{c} \log_{10} \frac{\sigma'_{o} + \Delta \sigma_{\text{avg.}}}{\sigma'_{o}}$$
.....(5.8b)

(iii) If  $\sigma'_p > \sigma'_o$  (OCR > 1), the soil is overconsolidated, and

(a) If  $\sigma'_p \geq \sigma'_o + \Delta \sigma_{avg.}$  then;

$$\Delta e = C_s \log_{10} \frac{\sigma'_o + \Delta \sigma_{avg.}}{\sigma'_o}$$
....(5.8c)

**(b)** If  $\sigma'_p < \sigma'_o + \Delta \sigma_{avg.}$  then;

**5.** Calculate the consolidation settlement by:

where,  $e_0 = \omega_0 \cdot G_s$ 

## Method (B):

- **1.** For thick clay layer, better results in settlement calculation can be obtained by dividing a given clay layer into (n) sub-layers.
- 2. Calculate the effective stress  $\sigma'_{o(i)}$  at the middle of each clay sub-layer.
- 3. Calculate the increase of stress at the middle of each sub-layer  $\Delta \sigma_{(i)}$  due to the applied load.
- 5. Calculate  $\Delta e_{(i)}$  for each sub-layer from Eqs.(5.8a to 5.8e) mentioned before in method (A) –step 3, whichever is applicable.
- 5. Calculate the total consolidation settlement of the entire clay layer from:

$$S_{c} = \sum_{i=1}^{n} \Delta S_{c} = \sum_{i=1}^{n} \frac{\Delta e_{i}}{1 + e_{o}} \Delta H_{i} \quad \text{where} \quad e_{o} = \omega_{o}.G_{s} \quad \text{(5.9)}$$

		Va	lues at m	id-point	of each s	ub-layer	
Layer	$\sigma'_{o(i)}$	$\Delta \sigma_{(i)}$	$\Delta e_{(i)}$	ω <sub>o</sub>	e <sub>o</sub>	$\Delta H_{i}$	$\frac{\Delta e_{(i)}}{1 + e_o} \Delta H_i$
1							
2							
3							
							$S_c = \sum$



Fig.(5.5): Calculation of consolidation settlement Methods.

## 4.6.2 Oedometer or $\,m_{\nu}\,$ Method:

From oedometer test, the values of volume change for each pressure increment is obtained as:

$$m_v = \frac{a_v}{1 + e_o}$$
 but  $a_v = \frac{\Delta e}{\Delta P}$  and  $\Delta H = \frac{\Delta e}{1 + e_o} H_t$  therefore;  $m_v = \frac{1}{\Delta p} \frac{\Delta H}{H_t}$ 

where,

 $a_v = \text{coefficient of compressibility of soil sample.}$ 

 $e_0$  = initial void ratio of soil sample.

 $\Delta e$  = the change in void ratio corresponding to a pressure change  $\Delta p$ .

 $\Delta p = \Delta \sigma$  = change in stress.

 $H_t$  = total thickness of the clay soil layer.

 $\Delta H$  = change in thickness, and

 $m_v =$  coefficient of volume compressibility of soil sample determined during an oedometer test for each pressure increment applied above the vertical effective stress or overburden pressure  $P'_o$ at the depth from which the sample was taken. <u>If the applied stress or</u>  $m_v$  <u>values vary with</u> <u>depth, then the soil deposit must be divided into layers and the change in thickness determined</u> <u>for each layer</u>. Typical values of  $m_v$  for different clay types are given in **Table (5.10)**.

Type of clay	$m_v m^2/MN$
Very stiff heavily	< 0.05
Overconsolidated clay	0.05 - 0.1
Firm overconsolidated clay, Laminated clay, weathered clay	0.1 - 0.3
Soft normally consolidated clay	0.3 – 1.0
Soft organic clay, sensitive clay	0.5 - 2.0
Peat	> 1.5





$\Delta \sigma$	m <sub>v</sub>	$\Delta H$

Oedometer or  $m_{\nu}$  method.

## 5.7 SKEMPTON - BJERRUM MODIFICATION FOR 3-DIMENTIONAL CONSOLIDATION

In one-dimensional consolidation tests, there is no lateral yield of the soil specimen and the ratio of minor to major principal effective stresses,  $K_o$ , remains constant. In that case, the increase of pore water pressure due to an increase of vertical stress is equal in magnitude, (i.e.,  $\Delta u = \Delta \sigma$ ) where  $\Delta u$  is the increase in pore water pressure and  $\Delta \sigma$  is the increase of vertical stress. While for actual simulation of field condition, in 3-dimensions, any point in a clay layer due to a given load suffers from lateral yield and therefore,  $K_o$  does not remain constant.

 $\therefore \qquad S_c = \rho \ S_{c \ (Oed)} \quad \dots \qquad (5.11)$ 

where,  $\rho$  = correction factor depends on pore-pressure parameter (A); obtained from **Fig.(4.6**).



Fig.(5.6): Settlement correction factor versus pore-pressure coefficient for circular and strip footings (after Skempton and Bjerrum, 1957).

## **Problem (5.4):** (consolidation settlement-C<sub>c</sub> method)

A circular foundation 2m in diameter is shown in the figure below. A normally consolidated clay layer 5m thick is located below the foundation. Determine the consolidation settlement of the clay.





#### (1) As one layer of clay of 5m thick:

At the center of clay:  $\sigma'_0 = 1.5(17) + 0.5(19-9.81) + 2.5(18.5-9.81) = 51.82 \text{ kN/m}^2$ For circular loaded area, the increase of stress below the center is given by:

$$\Delta \sigma = q \left\{ 1 - \frac{1}{\left[ \left( b / z \right)^2 + 1 \right]^{3/2}} \right\} \text{ where: } b = \text{the radius of the circular foundation,}$$

At mid-depth of the clay layer: z = 3.5m;  $\Delta \sigma = 150 \left\{ 1 - \frac{1}{\left[ (1/3.5)^2 + 1 \right]^{3/2}} \right\} = 16.66 \text{ kN/m}^2$  $\Delta e = C \log_{10} \frac{\sigma'_0 + \Delta \sigma}{\sigma} = 0.16 \log_{10} \frac{51.82 + 16.66}{\sigma} = 0.0194$ 

$$\Delta e = C_c \log_{10} \frac{\sigma_0 + 2\sigma}{\sigma_0'} = 0.16 \cdot \log_{10} \frac{\sigma_0 + 2\sigma}{51.82} = 0.019$$
$$S_c = \frac{\Delta e}{1 + e_0} H_t = \frac{0.0194}{1 + 0.85} (5)(1000) = \frac{52.4 \text{ mm}}{51.82}$$

(2) Divide the clay layer into (5) sub-layers each of 1m thick:

- <u>Calculation of effective stress at the middle of each sub-layer</u>  $\sigma'_{o(i)}$ : For 1<sup>st</sup>. Layer:  $\sigma'_{o(1)}=1.5(17) + 0.5(19-9.81) + 0.5(18.5-9.81) = 35.44 \text{ kN/m}^2$ For 2<sup>nd</sup>. Layer:  $\sigma'_{o(2)}=35.44 + 1.0(18.5-9.81) = 35.44 + 8.69 = 43.13 \text{ kN/m}^2$ For 3<sup>rd</sup>. Layer:  $\sigma'_{o(3)}=43.13 + 8.69 = 51.81 \text{ kN/m}^2$ For 4<sup>th</sup>. Layer:  $\sigma'_{o(4)}=51.81 + 8.69 = 60.51 \text{ kN/m}^2$ For 5<sup>th</sup>. Layer:  $\sigma'_{o(5)}=60.51 + 8.69 = 69.20 \text{ kN/m}^2$
- <u>Calculation of increase of stress below the center of each sub-layer</u>  $\Delta \sigma_{(i)}$ :

For 1<sup>st</sup>. Layer: 
$$\Delta \sigma_{(1)} = 150 \left\{ 1 - \frac{1}{\left[ (1/1.5)^2 + 1 \right]^{3/2}} \right\} = 63.59 \text{ kN/m}^2$$
  
For 2<sup>nd</sup>. Layer:  $\Delta \sigma_{(2)} = 150 \left\{ 1 - \frac{1}{\left[ (1/2.5)^2 + 1 \right]^{3/2}} \right\} = 29.93 \text{ kN/m}^2$   
For 3<sup>rd</sup>. Layer:  $\Delta \sigma_{(3)} = 150 \left\{ 1 - \frac{1}{\left[ (1/3.5)^2 + 1 \right]^{3/2}} \right\} = 16.66 \text{ kN/m}^2$   
For 4<sup>th</sup>. Layer:  $\Delta \sigma_{(4)} = 150 \left\{ 1 - \frac{1}{\left[ (1/4.5)^2 + 1 \right]^{3/2}} \right\} = 10.46 \text{ kN/m}^2$   
For 5<sup>th</sup>. Layer:  $\Delta \sigma_{(5)} = 150 \left\{ 1 - \frac{1}{\left[ (1/5.5)^2 + 1 \right]^{3/2}} \right\} = 7.14 \text{ kN/m}^2$ 

Layer no.	ΔH <sub>i</sub> m	$\sigma'_{o(i)}$ kN/m <sup>2</sup>	$\Delta \sigma_{(i)}$ kN/m <sup>2</sup>	$\Delta e^{*}_{(i)}$	$\frac{\Delta e_{(i)}}{1 + e_o} \Delta H_i$ <b>m</b>
1	1	35.44	63.59	0.0727	0.0393
2	1	43.13	29.93	0.0366	0.0198
3	1	51.82	16.66	0.0194	0.0105
4	1	60.51	10.46	0.0111	0.0060
5	1	69.20	7.14	0.00682	0.0037
					$\sum = 0.0793$

$$\Delta e^{*}_{(i)} = C_{c} \log_{10} \frac{\sigma'_{o(i)} + \Delta \sigma_{(i)}}{\sigma'_{o(i)}}; C_{c} = 0.16, e_{o} = 0.85, S_{c} = 0.0793 \text{ m} = \underline{79.3 \text{ mm}}.$$

#### (3) Weighted average pressure increase (Simpson's rule):

At the center of clay: 
$$\sigma'_{0} = 1.5(17) + 0.5(19-9.81) + 2.5(18.5-9.81) = 51.82 \text{ kN/m}^{2}$$
  
At  $z = 1.0m$  from the base of foundation:  $\Delta \sigma = 150 \left\{ 1 - \frac{1}{[(1/1)^{2} + 1]^{3/2}} \right\} = 75 \text{ kN/m}^{2}$   
At  $z = 3.5m$  from the base of foundation:  $\Delta \sigma = 150 \left\{ 1 - \frac{1}{[(1/3.5)^{2} + 1]^{3/2}} \right\} = 16.66 \text{ kN/m}^{2}$   
At  $z = 6.0m$  from the base of foundation:  $\Delta \sigma = 150 \left\{ 1 - \frac{1}{[(1/6)^{2} + 1]^{3/2}} \right\} = 6.04 \text{ kN/m}^{2}$   
 $\therefore \Delta \sigma_{\text{avg.}} = \frac{1}{6} (\Delta \sigma_{\text{t}} + 4\Delta \sigma_{\text{m}} + \Delta \sigma_{\text{b}}) = \frac{1}{6} [75 + 4(16.66) + 6.04] = 24.61 \text{ kN/m}^{2}$   
 $\Delta e = C_{\text{c}} \log_{10} \frac{\sigma'_{\text{o}} + \Delta \sigma}{\sigma'_{\text{o}}} = 0.16 \log_{10} \frac{51.82 + 24.61}{51.82} = 0.027$   
 $S_{\text{c}} = \frac{\Delta e}{1 + e_{0}} \text{H}_{\text{t}} = \frac{0.027}{1 + 0.85} (5)(1000) = 72.9 \text{ mm}$ 

#### **Problem (5.5):** (consolidation settlement $-m_v$ method)

A building is supported on a raft of  $(30m \times 45m)$ , the net pressure being 125 kN/m<sup>2</sup> as shown in the figure below. Determine the settlement under the center of the raft due to consolidation of the clay.



#### Solution:

From Ch.(4) the vertical stress below the corner of flexible rectangular or square loaded area  $\Delta \sigma_z = I.q_0$ At mid-depth of the layer, z = 23.5m below the center of the raft: m/z = 22.5/23.5 = 0.96 and n/z = 15/23.5 = 0.64 therefore; I = 0.140  $\Delta \sigma_z = (4)(0.140)(125) = 70 \text{ kN/m}^2$   $S_c = m_v.H_t.\Delta \sigma$  ......(5.10)  $S_c = (0.35)(70)(4)(1000) = 98 \text{ mm.}$ 

## **5.8 SECONDARY CONSOLIDATION SETTLEMENT**

It occurs after the primary consolidation settlement has finished when all pore water pressures have dissipated (see **Fig.(5.7**)). Secondary consolidation can be ignored for hard or overconsolidated soils. But, it is highly increased for organic soil such as peat. This can explained due to the redistribution of forces between particles after large structural rearrangements that occurred during the normal consolidation stage of the soil.



Fig. (5.7): Definition of secondary compression.

$$S_{c_s} = C_{\alpha}.H.\log_{10}\frac{t_2}{t_1}$$
.....(5.12)

where,  $S_{cs}$  = secondary consolidation settlement.

 $C_{\alpha}$  = coefficient of secondary consolidation; obtained from table below.

H =thickness of clay layer.

 $t_1 = time of primary consolidation settlement, and$ 

 $t_2$  = time of secondary consolidation settlement.

To determine 
$$t_1$$
: from  $T_v = \frac{C_v \cdot t}{H^2}$  take  $T_v = 1.0$  and  $t = t_1$ ; then  $1.0 = \frac{C_v \cdot t_1}{H^2}$  or  $t_1 = \frac{H^2}{C_v}$ 

Type of clay	Cα
Normally consolidated clay	0.005-0.02
Plastic or organic soil	≥0.03
Hard clay or overconsolidated clay with $O.C.R > 2$	0.001 - 0.0001

## Problem (5.6): (Total settlement)

As shown in the figure below, a footing 6m square, carrying a net pressure of 160 kN/m<sup>2</sup> is located at a depth of 2m in a deposit of stiff clay 17m thick; a firm stratum lies immediately below the clay. Form Oedometer tests on specimens of the clay, the value of  $m_v$  was found to be 0.13 m<sup>2</sup>/MN and from Triaxial tests the value of A was found to be 0.35. The undrained Young's modulus for the clay is estimated to be 55 MN/m<sup>2</sup>. Determine the total settlement under the center of the footing.



Solution:

(1) Immediate settlement (Using Bjerrum method):

From **Fig.(5.4):** for H/B = 15/6 = 2.5, L/B = 1 and D<sub>f</sub>/B = 2/6 = 0.33

 $\mu_0 = 0.91$  and  $\mu_1 = 0.60$ 

$$S_{i(average)flexible} = \mu_0.\mu_1 \frac{q.B}{E_u}.....(5.7)$$
  

$$S_{i(average)flexible} = (0.91)(0.60) \frac{(160)(6)(1000)}{(55x1000)} = 9.5 \text{ mm}$$

#### (2) Consolidation settlement (m<sub>v</sub> - method):

From Ch.(4), the vertical stress below the corner of flexible rectangular or square loaded area

$$\Delta \sigma_z = I.q_o$$

At mid-depth of each 3 m depth as shown in the table below:

Layer no.	z (m)	m/z, n/z	I From Ch.(4) Fig.(4.15)	$\Delta\sigma'$ (kN/m <sup>2</sup> )	$S_{c(oed)} = m_v.H_t.\Delta\sigma'$ (mm)
1	1.5	2.00	0.233	149	58.1
2	5.5	0.67	0.121	78	30.4
3	7.5	0.40	0.060	38	15.8
4	10.5	0.285	0.033	21	8.2
5	13.5	0.222	0.021	13	5.1
					$\sum = 116.6$

For 1<sup>st</sup>. Layer: m/z = 3/1.5 = 2.00 and n/z = 3/1.5 = 2.00 therefore; I = 0.233

 $\Delta \sigma'_{z} = (4)(160)(I)....(kN/m^{2})$ 

$$S_{c(oed)} = m_v.H_t.\Delta P$$
 .....(5.10)

 $S_{c(oed)} = (0.13)(\Delta \sigma'_z)(3)(1000) \dots (mm).$ 

#### (3) Correction for A pore water pressure:

From **Fig.(5.6):** for H/B = 15/6.77 = 2.2 (equivalent diameter = 6.77 m) and A = 0.35;  $\rho_{circle} = 0.55$  then,  $S_{c(oed)} = (0.55)(116.6) = 64$  mm.

: Total settlement =  $S_T = S_i + S_c = 9.5 + 64 =$ <u>73.5 mm</u>

## 5.9 DEGREE OR RATE OF SETTLEMENT

It is the ratio of consolidation at time (t) to that of 100% consolidation when the pore water pressure was diminishes. It is calculated as follows:

(1) First, from Oedometer tests, the coefficient of consolidation ( $C_v$ ) is calculated as:

where,  $m_v = volume.change.coefficient = \frac{a_v}{1 + e_o}$ ,  $a_v = \frac{\Delta e}{\Delta p} = compressibility coefficient and k = permeability of soil.$ 

(2) Second, the time factor  $(T_v)$  is calculated from:

$$T_v = \frac{C_v t}{(H_d)^2}$$
.....(5.14)

where,  $H_d$  (drainage path) = H (for one-way drainage) and = H/2 (for two-way drainage).

(3) Third, with  $(T_v)$  value obtained from Eq. (5.14), the degree of consolidation U% at any time (t) is calculated from **Fig.(5.8**) depending on the distribution of the excess pore water pressure; or one of the following equations:

$$T_v = \frac{\pi}{4} \left(\frac{U\%}{100}\right)^2$$
 for  $U \le 60\%$  .....(5.15a)

$$T_v = 1.781 - 0.933 \log_{10}(100 - U\%)$$
 for  $U > 60\%$  .....(5.15b)

(4) From the degree of consolidation U% at any time (t), the settlement at any time is calculated from the following relation if the total settlement is known:

$$U_{t} = \frac{S_{t}}{S_{\infty}} = \frac{\text{Settlement.at.any.time}(t)}{\text{Total.settlement}}$$
....(5.16)

where,  $S_{\infty} = S_T = S_i + S_c + S_{sc}$ .

<u>Note:</u> U% for any layer depends on pore water pressure distribution using Figs.(5.20a and 5.20b) to find  $U_t$  at any time. But, for other shapes use division to suit with figures above as shown in the following example.





Fig.(5.8): Variation of average degree of consolidation and time factor (for EPWP conditions given in Figs. a, and b).



#### **Problem (5.7):** (degree of consolidation)

For pore water pressure distribution across a clay soil layer shown below, find the average degree of consolidation after (15) years.



Solution:

$$T_v = \frac{C_v \cdot t}{(H_d)^2} = \frac{(0.4)(15)}{(4)^2} = 0.375$$

From **Fig.(5.8**) for  $T_v = 0.375$ ;  $U_1 = 65\%$  (curve 1) and

for 
$$T_v = 0.375$$
;  $U_2 = 75\%$  (curve 3)  
 $U_{avg.} = \frac{U_1.A_1 + U_2.A_2}{\sum A} = \frac{0.65(4)(60) + 0.75(4)(40)/2}{(\frac{100+60}{2})(4)} = 0.675 = 67.5\%$ 

#### **Problem (5.8):** (degree of consolidation)

For a layer of clay of 4m thick, if the coefficient of consolidation  $C_v = 0.4 \text{ m}^2/\text{year}$ , and PWP distribution is given as below. Calculate: (1) the average degree of consolidation after 20 years, and (2) the time required for 62 % consolidation.



(1) 
$$T_v = \frac{C_v t}{(H_d)^2} = \frac{(0.4)(20)}{(4)^2} = 0.50$$

From Fig.(5.8) for  $T_v = 0.50$ ;  $U_1 = 76\%$  (curve 1) and for  $T_v = 0.50$ ;  $U_2 = 69\%$  (curve 2)

$$U_{\text{avg.}} = \frac{U_1.A_1 + U_2.A_2}{\sum A} = \frac{0.76(4)(100) + 0.69(4)(150)/2}{(\frac{100 + 250}{2})(4)} = 0.73 = 73\%$$

(2) To calculate the time required for any degree % of consolidation, take several times  $t_{i(year)}$  and find the corresponding  $U_{i(avg.)}$  as follows:

t <sub>i</sub> ( <b>year</b> )	T <sub>v</sub>	$U_1$	U <sub>2</sub>	$U_{avg.} = \frac{U_1.A_1 + U_2.A_2}{\sum A}$ (%)
10	0.25	0.55	0.45	50.7 < 62
12	0.30	0.62	0.50	56.8 < 62
15	0.375	0.67	0.57	62.7 ≈62
18	0.45	0.72	0.64	68.5 > 62

## Sample of Calculation:

• For t = 10 (years):  $T_v = \frac{C_v \cdot t}{(H_d)^2} = \frac{(0.4)(10)}{(4)^2} = 0.25$ 

From Fig. (5.8) for  $T_v = 0.25$ ;  $U_1 = 55\%$  (curve 1) and

for 
$$T_v = 0.25$$
;  $U_2 = 45\%$  (curve 2)

$$U_{avg.} = \frac{U_1.A_1 + U_2.A_2}{\sum A} = \frac{0.55(4)(100) + 0.45(4)(150)/2}{(\frac{100 + 250}{2})(4)} = 0.507 = 50.7\%$$

• After drawing  $U_{i(avg.)}$  versus  $t_{i(year)}$  as obtained from table above; it can be seen that *the required time for 62 % consolidation = 15 (years)*.

#### **Problem (5.9):** (consolidation for layered soils)

A raft foundation is placed at surface of a normally consolidated clay layers with internal sand drain layers as shown in the figure below. Determine the % degree of consolidation after 10 years if the PWP distribution is as given in the same figure.



#### Solution:

(1) Calculate  $(T_v)$  for each clay layer; 1, 2, 3:

$$T_{v1} = \left[\frac{C_{v1} \cdot t}{(H_1)^2}\right] = \frac{0.4(10)}{(2/2)^2} = 4,$$
  

$$T_{v2} = \left[\frac{C_{v2} \cdot t}{(H_2)^2}\right] = \frac{0.3(10)}{(3/2)^2} = 1.333, \text{ and}$$
  

$$T_{v3} = \left[\frac{C_{v3} \cdot t}{(H_3)^2}\right] = \frac{0.2(10)}{(4)^2} = 0.125$$

(2) Calculate  $(S_{C_i})$  for each clay layer; 1, 2, 3:

 $\begin{array}{ll} \underline{for \ normally \ consolidated \ clay}: \quad S_{Ci} = \frac{C_c}{1 + e_o} H_t \ \log_{10} \frac{\sigma'_o + \Delta \sigma}{\sigma'_o} \\ \underline{for \ clay \ layer \ (1):} \\ \sigma'_o = \gamma.H = 18(1) = 18 \ kN/m^2, \quad \Delta \sigma = 100(10)(20)/(10 + 1)(20 + 1) = 86.580 \ kN/m^2 \\ \therefore \qquad \qquad S_{Ci} = \frac{0.1}{1 + 0.60} (200) \log_{10} \frac{18 + 86.580}{18} = 9.55 \text{cm} \end{array}$ 

$$\sigma'_{o} = \gamma.H = 18(2) + 19(3) + 20(2) = 133 \text{ kN/m}^{2}, \ \Delta\sigma = 100(10)(20)/(10+7)(27) = 43.573 \text{ kN/m}^{2}$$
  
$$\therefore \qquad S_{C3} = \frac{0.08}{1+0.60} (400) \log_{10} \frac{133+43.573}{133} = 2.46 \text{cm}$$

(3) Calculate (U %) for each clay layer; 1, 2, 3 after (10) years: Total settlement for all layers:

$$S_{c} = S_{c1} + S_{c2} + S_{c3} = 9.55 + 5.85 + 2.46 = 16.86 \text{ cm}$$

From Fig.(5.8): *for clay layer (1):* for  $T_{v_1} = 4$ ;  $U_1 = 100\%$  (curve 1)

for clay layer (2): for 
$$T_{y_2} = 1.33$$
;  $U_2 = 95\%$  (curve 1)

for clay layer (3): the PWP distribution consists of cases (1 + 2) and calculated as:



for  $T_{v_3} = 0.125$ ;  $U_1 = 0.38$  (curve 1) and  $U_2 = 0.22$  (curve 2)

$$U_{3} = \frac{U_{1}.A_{1} + U_{2}.A_{2}}{\sum A} = \frac{0.38(4)(50) + 0.22(4)(50)/2}{(\frac{50 + 100}{2})(4)} = 0.326 = 33\%$$

The average degree of consolidation after (10) years for all layers is calculated from:

$$U_{i(avg.)} = U_{(t)} = \frac{1}{S_c} (S_{c1}U_1 + S_{c2}U_2 + S_{c3}U_3 + \dots)$$
  
$$U_{i(avg.)} = \frac{1}{16.86} [(9.55)(1.00) + (4.85)(0.95) + (2.46)(0.33)] = 0.89 = 89 \%$$